



Installation



Note! If your handlebar requires better grip for holding the RC4 in place, apply the rubber band around the handlebar.

Replacing the battery



Button operation and feedbacks



Tap ^[*]



Double tap ^[*]



Press for "n" ^[*]



Audio feedback: voice message from the earphones ^[*]



Visual feedback: LED flashes

^[*] An audio feedback ("**Beep**") follows each impulse

Power On/Off

Power On



Center Button

Deep Sleep



[(+) Button + Center Button]


Battery check

Power On



70% > 100%
30% > 70%
0% > 30%

Bluetooth® pairing




Note! You can control the AGV intercom using the Remote control only if they are paired. The AGV Remote Control supports AGV headsets with Bluetooth® 4.1 or higher.



Note! To complete the connection, refer to the AGV intercom User manual.

Factory reset



AGV intercom control

To control your AGV intercom using the AGV Remote Control, please refer to the intercom's *Quick Start Guide* to manage phone, music, communication and other functionalities.

Dainese S.p.A.

Via Louvigny, 35
36060 Colceresa (VI)
Italy

ph: +39 0424 410711
fax: +39 0424 410700

www.agv.com

SENA

Bluetooth


Remote_Control_QSG_ENG_20190315




Remote Control


 Quick start guide

Overview



 **Note!** The buttons **(-)**, **Center** and **(+)** replicate the AGV intercom functionalities through the same operating logic.

Getting started



Remove the plastic tape from the battery slot to begin using the AGV Remote Control.