





## Boom Microphone Type




## Battery Check




## Button Operation




## Power On/Off




## Volume Adjust



## Configuration Menu





## Start/End Intercom



## Bluetooth Pairing


**Phone, MP3, GPS**




Enter     PIN

## Headset Pairing



## Intercom



## Music



## Mobile Phone



**Note:**  
Voice Dial and Redial functions are available only in stand-by mode and not available during music playback.

A full version of the manual is downloadable at [www.givimoto.com](http://www.givimoto.com)

HEADQUARTERS: GIVI Srl \_ Flero (BS) Italy  
Fax +39 030 35 80 518 - [info@givi.it](mailto:info@givi.it) - [www.givimoto.com](http://www.givimoto.com)

