


























RC4

Operation for Headset




















	Operation	Button Command
Basic	Volume	 
		 
	Configuration menu	 
Mobile Phone	Answer phone call	 
	End phone call	 
	Voice dial	 
	Speed dial	 
	Reject incoming call	 
Intercom	Intercom pairing	 
		 
	Start Group Intercom	 &  
	End all intercoms	 



SCHUBERTH

RC4

Operation for Headset

	Operation	Button Command
Music	Play/pause Bluetooth music	  1sec
	Track forward/back	 or   1sec
FM Radio	FM radio on/off	  1sec
	Select preset	  1sec
	Seek stations	 or   
	Scan up FM band	  1sec
	Stop scanning	  1sec
Save preset while scanning	 	



SCHUBERTH